
LUNARIA

LIGHTING LONDON

Elwen Fabric Wall Light

FITTING & CARE GUIDE / V2




lunarialight.com

hello@lunarialight.com

01 / YOUR LIGHT AT A GLANCE

Elwen Fabric Wall Light

Elwen is a single-shade wall light with a tapered fabric shade above a decorative wood and metal base. Its 38 cm height and narrow front profile suit careful placement beside furniture, with the shade kept clear of moving items.



OVERALL HEIGHT
38 cm

FRONT WIDTH
15 cm

SHADE COLOURS
White, Green or Red

LIGHT SOURCE
One E14 LED bulb

INCLUDED LIGHT
Warm white

Confirm the single-shade model and your chosen White, Green or Red fabric before preparing the wall position.

Tapered fabric shade

The single shade narrows towards the top and surrounds the light source; protect the fabric from squeezing and sharp edges.

Decorative base

The shaped wood and metal base sits beneath the shade, forming the lower outline and providing a firm handling area.

Wall cup


The rounded metal wall cup meets the wall behind the decorative body; its visible position helps plan the fitting centre.

Place the shade around daily movement

Mark the full 38 cm height on the wall before choosing the mounting point. Beside a bed, check the seated position, headboard and bedside table together. Beside a cupboard, open its door fully. Leave the fabric clear of curtains, bedding and other objects that could brush against or cover it.


ELWEN FABRIC WALL LIGHT

Prepare & fit




Before fitting

Switch off the lighting circuit at the consumer unit and verify it is dead. Electrical connections and testing must be completed by a competent installer. Keep the light supported until it is securely fixed.



01 Check the position



02 Support the body



03 Check before use

Protect the fabric first

Clear a dry work area and put tools in a separate tray. Remove wrapping without dragging staples or tape across the shade, then check the fabric and its outline for damage.

Check the supplied bulb

Identify the included E14 LED bulb and keep its packaging for future replacement details. Before fitting, check its rating and shape against the actual holder and shade opening.

1 Agree the wall position

Use the full shade height and width to check the position against surrounding furniture. Check the wall support and electrical point before marking fixing holes from the actual mounting parts.

2 Carry by the solid body

Support the base and wall body together when moving the fitting. Keep the fabric away from your grip; lifting by the shade can distort its shape or stress its attachment.

3 Keep the shade protected during work

Leave the shade out of contact with tools and the wall during preparation. Any shade removal or fitting must follow the arrangement provided with this single-shade product, with the fabric kept clear.

4 Check the shade and bulb together


Before use, confirm that the shade sits steadily and is clear of the bulb. Check the outline from the front and side, without twisting the fabric to correct the position of the base.

ELWEN FABRIC WALL LIGHT

Use & look after

One replaceable E14 light source

Elwen uses one E14 LED bulb, with a warm-white bulb included. It is supplied as a non-dimmable light. Keep the bulb's specification for replacements, checking the fitting's own limits as well as the base size. Switch off and let the bulb cool before using the access method established by the installer.



Brush the fabric softly

Use a soft, dry brush on the cool shade. Brush lightly in small sections, without soaking the fabric or pulling at its edges.



Wipe the solid surfaces

Dust the wood and metal with a soft, dry cloth. Keep furniture polish, solvent cleaners and spray droplets away from the fabric and holder.

If something needs attention

The shade appears tilted	With the light off, check visually whether the body or shade is leaning. Ask the installer to correct its seating; do not twist the fabric.
The bulb touches the shade	Switch off and allow it to cool. Have the bulb size and shade seating checked before reuse; never push the fabric away from a hot bulb.
The fabric is dented or marked	Keep sharp tools, water and heat away from the affected area. Photograph the damage and contact LUNARIA before trying to reshape or clean it aggressively.

BEFORE SWITCHING ON

- ✓ Fitting secure
- ✓ Fragile parts stable
- ✓ No trapped cable
- ✓ Electrical checks complete