
LUNARIA

LIGHTING LONDON

Oren Funnel Pendant Light

FITTING & CARE GUIDE / V2




lunarialight.com

hello@lunarialight.com

01 / YOUR LIGHT AT A GLANCE

Oren Funnel Pendant Light

Oren has a long narrow upper section that flares into a downward-facing conical shade. A black cable connects it towards the ceiling rose. Check the full rigid body and the desired hanging position together before the installer sets the finished drop.



BODY
36 cm high, 15 cm diameter

FORM
Downward-facing funnel

COLOURS
Grey, White, Blue or Green

CONNECTION
Ceiling pendant with black cable

Match Grey, White, Blue or Green to your order. If fitting several pendants, check every shade colour before planning their positions.

Narrow upper body

The long upper section leads into the funnel-shaped shade. Protect it from bending rather than using it as a lever.

Flared shade

The wider lower cone surrounds the downward light opening. Support the shade carefully and check the rim for dents.

Cable and ceiling rose


The black cable rises to the round ceiling rose. Keep it free from kinks and do not lift by it.

Measure the body and the hanging drop

Include the full 36 cm rigid body when measuring the proposed drop above a table, bedside or walkway. Check sightlines from sitting and standing positions, along with access to nearby cupboards. Mark each centre when planning a row. The installer should assess the actual cable restraint and ceiling support before setting any final cable length.


ORENFUNNEL PENDANT LIGHT

Prepare & fit




Before fitting

Switch off the lighting circuit at the consumer unit and verify it is dead. Electrical connections and testing must be completed by a competent installer. Keep the light supported until it is securely fixed.



01 Check the position



02 Support the body



03 Check before use

Inspect the full body

Check the narrow section, flared cone and lower rim for dents or bending. Keep the shade on a clean, padded surface while unpacking the cable and any supplied loose parts.

Record the intended position

Measure the desired lowest point from the floor or furniture beneath it. Give that measurement to the installer so the complete rigid body is included when the drop is assessed.

1 Keep the cable untangled

Gently lay out the cable without pulling on either end or twisting the shade. Leave cable adjustment and restraint checks to the installer; do not cut the cable during unpacking.

2 Check each ceiling centre

For a row, check centre positions against the furniture before any holes are marked. Assess the actual ceiling construction, concealed services and supplied mounting arrangement separately at every intended position.

3 Support the shade during positioning

Hold the body from beneath while it is brought into position. Keep the cone clear of ladders and furniture, and do not rotate the narrow upper section to test for a thread.

4 Confirm the finished drop


After the installer has fitted the pendant, check the lowest point and sightline against the measurements. If several lights are installed, compare their positions without tugging on cables or twisting the bodies.

ORENFUNNEL PENDANT LIGHT

Use & look after

Light through the lower opening

The shade directs light through its lower opening. Keep that opening free of decorations and packing. Retain the lamp details supplied with the delivered fitting for future replacement, and ask the installer to show the correct access method. Switch off and allow the light to cool before cleaning or handling the lamp area.



Protect the painted shade

Use a soft, dry cloth on the cool cone, working lightly around its rim. Avoid abrasive pads and pressure that could dent the edge.



Dust the narrow section

Wipe the upper body without bending it or turning the shade. Keep liquids away from the cable entry and do not pull the cable while cleaning.

If something needs attention

The pendant hangs at the wrong height	Measure the desired change and contact the installer. Do not pull cable through the ceiling rose or loosen a visible part to alter the drop.
The body appears bent	Check it from more than one viewing angle and photograph the issue. Do not straighten the narrow section by hand; ask support to assess it.
The light does not come on	Check the normal wall switch, then keep the light off for safe inspection. Use the demonstrated lamp-access method only or arrange an installer check.

BEFORE SWITCHING ON

- ✓ Fitting secure
- ✓ Fragile parts stable
- ✓ No trapped cable
- ✓ Electrical checks complete