
LUNARIA

LIGHTING LONDON

Rustic Antler 6-Light Chandelier

FITTING & CARE GUIDE / V2




lunarialight.com

hello@lunarialight.com

01 / YOUR LIGHT AT A GLANCE

Rustic Antler 6-Light Chandelier

The Rustic Antler chandelier has six light positions within a branching decorative form. Its sculpted resin antlers sit on an iron structure, making the central body the sensible handling point while the projecting tips are protected from knocks.



CONFIGURATION
Six-light chandelier

DECORATIVE MATERIAL
Sculpted resin antlers

STRUCTURE
Iron

SUSPENSION
Chain pendant

BULB BASE
E14

Check that the delivered fitting matches the six-light order. Keep any loose decorative pieces and hardware with their original packaging until the installer has identified them.

Central body

The central structure brings the branches together. Support this area while unpacking rather than lifting the chandelier by its decorative extremities.

Decorative antlers

The resin branches create the silhouette and extend beyond the body. Protect their tips from the ladder, walls and neighbouring parts.

Chain suspension


The chain forms the visible hanging section above the chandelier. Its attachment and length setting belong to the installer's support assessment.

Measure the full antler spread

Measure to the outermost antler tips, not just the central body. Check the finished lowest point above the floor or table and the route used to bring the chandelier into the room. Allow for chairs, doors and nearby furniture when deciding its centre, then give the installer the chosen height.


RUSTIC ANTLER 6-LIGHT CHANDELIER

Prepare & fit




Before fitting

Switch off the lighting circuit at the consumer unit and verify it is dead. Electrical connections and testing must be completed by a competent installer. Keep the light supported until it is securely fixed.



01 Check the position



02 Support the body



03 Check before use

Unpack across a clear surface

Lay out any loose pieces on a padded, stable surface with space between the antler tips. Check each for cracks before lifting the main body out of its protective packaging.

Plan the lift together

Arrange enough help to keep the chandelier controlled while the installer works. Clear the route, protect the table underneath and keep bulbs separate from the assembly until they are needed.

1 Assess the ceiling support

Check the actual assembled weight and the ceiling structure before choosing fixings. A previous light point or hook must be assessed for this chandelier rather than assumed suitable.

2 Check the delivered kit

Before raising it, identify the supplied structural parts and any loose decorative branches. Keep each piece supported on the padded surface while its correct location and attachment are established.

3 Set the finished position

Use the agreed lowest-point measurement when the installer sets the suspension. Check the chandelier's spread against nearby walls and furniture while it remains controlled; do not pull on antler tips to turn it.

4 Inspect all six light positions


Once the fitting is secured, check the bulbs against the E14 holder markings and their available space. Look for damaged antlers or tilted light positions before normal use.

RUSTIC ANTLER 6-LIGHT CHANDELIER

Use & look after

Keep replacement bulbs consistent

The six-light configuration uses E14 bulbs. When replacing one, match the holder limits and choose a consistent bulb shape and light appearance across the fitting. Switch off and allow every bulb to cool first. Do not move the chandelier by its branches to reach a light position.



Dust the resin branches

Use a soft, dry brush and light strokes around the sculpted texture. Work towards each tip gently rather than hooking the brush around it.



Clean without swinging

Use stable access and avoid pulling the suspended fitting towards you. Dust the cool body gently; do not soak resin or spray cleaner overhead.

If something needs attention

One bulb stays dark	Switch off and let all bulbs cool. Check the affected bulb against the holder marking using the access demonstrated by the installer; avoid moving the branch.
A branch or joint moves	Stop using the light and keep the area below clear. Ask the installer to inspect it; do not glue a joint or tighten it by trial.
The chandelier hangs unevenly	Photograph the whole fitting from two sides and contact the installer. Do not redistribute its weight by bending branches or altering the chain yourself.

BEFORE SWITCHING ON

- ✓ Fitting secure
- ✓ Fragile parts stable
- ✓ No trapped cable
- ✓ Electrical checks complete