
LUNARIA

LIGHTING LONDON

Taven Rattan Ceiling Light

FITTING & CARE GUIDE / V2




lunarialight.com

hello@lunarialight.com

01 / YOUR LIGHT AT A GLANCE

Taven Rattan Ceiling Light

Taven is a compact woven basket ceiling light with an open underside and a short connection to a black ceiling plate. The weave sits around a supporting frame. Handle that frame gently and keep individual strands free from pulling or crushing.



SHADE DIAMETER
20 cm

CEILING PLATE
10 cm diameter

LAMP
One E27 bulb included

SHADE
Open woven basket

The current Taven option is Ø 20 cm. Check the basket diameter and black ceiling plate against the delivered fitting and order.

Woven basket

The open weave forms the shade around the central lamp position. Its individual strands need protection from snagging and crushing.

Supporting frame

The dark frame gives the basket its shape. Hold the shade where it is supported rather than lifting by loose strands.

Black ceiling plate


The circular metal plate sits close above the basket on a short neck. It is separate from the woven surface.

Give the woven shade a clear position

Check the basket's actual diameter and height below the ceiling against nearby doors and cupboards. Keep the lower opening accessible for bulb care and ensure the shade will not be brushed by passing objects. Choose a dry indoor position, then confirm the existing cable point and suitable ceiling support before work begins.


TAVEN RATTAN CEILING LIGHT

Prepare & fit




Before fitting

Switch off the lighting circuit at the consumer unit and verify it is dead. Electrical connections and testing must be completed by a competent installer. Keep the light supported until it is securely fixed.



01 Check the position



02 Support the body



03 Check before use

Inspect the weave

Look around the basket for broken strands, crushed areas or a bent supporting frame. Unwrap gently so packaging does not snag in the weave; keep the open underside clear.

Check the included bulb

Locate the supplied E27 bulb and keep it protected while preparing the fitting. Compare its markings with the fitting label before use, and retain the bulb details for later replacement.

1 Keep the basket protected

Rest the light on a clean, padded surface without flattening the weave. Keep tools and loose fixings beside the fitting rather than inside the basket while the supplied parts are checked.

2 Assess the ceiling point

Check the actual ceiling support, concealed services and supplied mounting parts before marking holes. Use the delivered fitting; the outside diameter of the plate is not the fixing-hole spacing.

3 Support the framed body

Move the light with the supporting frame and main body held securely. Do not pull individual strands, lift through the weave or use the bulb as a handle during positioning.

4 Check the lamp clearance


Before use, check that the bulb is correctly seated and clear of the shade. Remove any visible protective packaging and confirm that the basket has not been crushed during handling.

TAVEN RATTAN CEILING LIGHT

Use & look after

One E27 bulb

Taven is supplied with an E27 bulb. Keep its specification for future replacement and follow the limits marked on the fitting; a larger bulb is not automatically suitable because the basket is open. Switch off and let the bulb cool before access. Keep fabric, decorations and other objects out of the basket.



Brush the woven surface

When the light is off and cool, use a soft, dry brush to remove dust from the weave. Follow the strands without pulling them.



Keep moisture away

Do not soak the basket or spray cleaner into the weave. Dust the metal plate separately with a dry cloth and avoid bending the frame.

If something needs attention

A woven strand is broken	Photograph the affected area before fitting or further use. Do not pull it out or use glue close to the bulb; contact support for advice.
The bulb touches the basket	Switch off and allow the bulb to cool. Have the bulb size and seating checked; do not reshape the basket to create more room.
The light is off or intermittent	Check the normal wall switch. With the supply isolated and bulb cool, check accessible bulb seating; ask the installer to investigate if the fault continues.

BEFORE SWITCHING ON

- ✓ Fitting secure
- ✓ Fragile parts stable
- ✓ No trapped cable
- ✓ Electrical checks complete